



# Boiler Monitoring

Use K, J, T, N, S, E, B and R-Type thermocouples connected directly to the ORB-X1 to measure temperature.

Connect a moisture sensor to the voltage inputs on the ORB-X1.

Use the ORB-X1 current source to measure pressure levels with a 4-20mA sensor.

Receive alerts online and via SMS or email.

Monitor and track boiler temperatures. Receive alerts if temperatures fall outside operational limits.

Measure pressure levels to ensure safe operation.

Check for water leaks.

Track power usage and receive instant alerts if power fails.

Measure vessel incline and vibration.

