



Electric Fence Monitoring

Monitor the voltage on your electric fence and receive alerts when the energizer is off, the voltage is low, or the fence wire is broken.

Save time not having to drive around checking your fencing.

At the same time, monitor whether gates are closed and the level in your water tank.

Receive email and SMS alerts



The ORB-X1-G includes a GPS system to accurately pinpoint the location of the fault.

Connect a PTE0705 electric fence monitor to the analog input to measure voltage.

Monitor gate closure with a simple reed-switch connected to an ORB input.

Monitor tank level with a 4-20mA pressure sensor.

Run off solar or AA batteries.