



Use the CAN bus to connect to temperature and absolute and differential pressure sensors.

Connect to CO₂ and other gas sensors using 4-20mA.

Generate warnings to allow preventative maintenance and alarms to protect the safety of the operator.

Integrated GPS tells you location of your vehicle.



In-Cab Air Quality

ISO 23875 Standardises Mining Cabin Air Quality Control System Requirements. Adoption of the practices outlined in the standard protect personnel inside operator enclosures from harmful respirable particulates and ensure safe levels of CO₂.

Monitor for positive pressure in the cab, use differential pressure to ensure functioning filters and monitor for CO₂ and other dangerous gasses.

Reduce the incidences of chronic health conditions in the work force.